

## New Carbon Monoxide Alarms



Carbon Monoxide Alarms shall be installed in each sleeping room or within 15 feet outside of each bedroom door on each level where there are bedrooms.

### Supporting Documents

 [Carbon Monoxide Alarms](#)

Source URL (retrieved on 2012-05-09 23:26): <http://westlinnoregon.gov/building/new-carbon-monoxide-alarms>